

# Mt 061 Instrumentation Amplifier In Amp Basics Workbook

## linear integrated circuits important questions 2 marks

Linear integrated circuits (ICs) are fundamental components in analog electronics, playing a crucial role in various applications such as amplification, filtering, and signal processing. For students, engineers, and enthusiasts preparing for exams or interviews, understanding the key questions related to linear ICs is essential. These questions often focus on basic concepts, functions, characteristics, and applications, typically awarded 2 marks in academic assessments. In this comprehensive guide, we delve into the most important 2-mark questions on linear integrated circuits, providing clear explanations to enhance your understanding and exam readiness.

## Introduction to Linear Integrated Circuits

### What Are Linear Integrated Circuits?

Linear ICs are a class of integrated circuits that operate in the linear region of their transfer characteristics. Unlike digital ICs, which switch between discrete states, linear ICs produce output signals that are proportional to their input signals, making them suitable for amplification and analog signal processing.

### Basic Characteristics of Linear ICs

- Operate in the analog domain
- Provide amplification with minimal distortion
- Consist of multiple transistors, resistors, and other components
- Used in audio, radio, and instrumentation systems

## Common Types of Linear ICs and Their Functions

### Operational Amplifiers (Op-Amps)

Op-amps are versatile linear ICs used for amplification, filtering, mathematical operations, and more.

### Voltage Regulators

Maintain a constant output voltage despite variations in input voltage or load conditions.

## Comparators

Compare two voltages and output a digital signal indicating which is higher.

## Amplifiers

Used for audio amplification, instrumentation, and signal conditioning.

## Important 2-Mark Questions on Linear Integrated Circuits

This section covers frequently asked questions that are typically answered in two marks, providing concise yet comprehensive responses.

### 1. What is an operational amplifier?

An operational amplifier (op-amp) is a high-gain voltage amplifier with differential inputs and a single-ended output, used for various analog signal processing tasks.

### 2. What are the characteristics of an ideal op-amp?

An ideal op-amp has infinite open-loop gain, infinite input impedance, zero output impedance, zero input bias current, and infinite bandwidth.

### 3. Define bandwidth of an op-amp.

Bandwidth refers to the range of frequencies over which the op-amp can operate effectively without significant gain reduction.

### 4. What is slew rate in op-amps?

Slew rate is the maximum rate at which an op-amp's output voltage can change, typically expressed in volts per microsecond (V/ $\mu$ s).

### 5. What is the purpose of a voltage regulator IC?

A voltage regulator IC maintains a constant output voltage regardless of variations in input voltage or load current.

### 6. Name two types of voltage regulators.

- Linear voltage regulators
- Switching voltage regulators

## **7. What is the function of a comparator?**

A comparator compares two input voltages and outputs a digital signal indicating which input is higher.

## **8. Differentiate between linear and switching regulators.**

Linear regulators provide a steady output voltage by dissipating excess voltage as heat, while switching regulators efficiently convert voltage levels using high-frequency switching.

## **9. What is the typical application of an op-amp?**

Op-amps are used in amplification, filtering, oscillators, and mathematical operations like addition and integration.

## **10. What is the significance of input impedance in op-amps?**

High input impedance minimizes loading effects on the source signal, ensuring signal integrity.

## **Key Concepts and Definitions**

### **11. What is gain in an op-amp?**

Gain refers to the amplification factor, usually defined as the ratio of output voltage to input voltage.

### **12. Define common-mode and differential gain.**

- Common-mode gain: Amplification of signals common to both inputs.
- Differential gain: Amplification of the difference between the two input signals.

### **13. What is the purpose of feedback in op-amp circuits?**

Feedback stabilizes gain, improves bandwidth, reduces distortion, and sets the desired operation mode.

### **14. What is a voltage follower?**

A voltage follower is an op-amp configuration where the output voltage directly follows the input voltage, providing high input impedance and low output impedance.

### **15. What is a Wien bridge oscillator?**

It is a type of oscillator circuit that generates sine waves using a bridge network and an amplifier, often implemented with op-amps.

## **Applications of Linear Integrated Circuits**

### **16. Where are voltage regulators used?**

In power supplies to provide stable voltages for electronic devices.

### **17. How are op-amps used in filters?**

Op-amps form active filters such as low-pass, high-pass, band-pass, and band-stop filters for signal processing.

### **18. What role do comparators play in digital circuits?**

They serve as decision-making devices, converting analog signals into digital signals.

### **19. What is the importance of temperature stability in ICs?**

Ensures consistent performance of ICs across temperature variations, crucial for reliable operation.

### **20. Name some popular linear IC manufacturers.**

- Texas Instruments
- Analog Devices
- National Semiconductor
- STMicroelectronics

## **Additional Important Questions for Quick Revision**

- What is the difference between voltage regulator ICs and power regulator ICs?
- Explain the concept of offset voltage in op-amps.
- What are the advantages of using ICs over discrete components?

- Describe the role of a differential amplifier in linear ICs.
- How does temperature affect the operation of linear ICs?

## Tips for Exam Preparation on Linear ICs

- Focus on understanding the basic concepts and functions of different linear ICs.
- Memorize key definitions such as bandwidth, slew rate, and gain.
- Practice drawing circuit diagrams of common configurations like voltage followers and inverting amplifiers.
- Review the characteristics and applications of op-amps, voltage regulators, and comparators.
- Solve previous year questions to familiarize yourself with common question patterns.

## Conclusion

Mastering the important questions related to linear integrated circuits is vital for excelling in exams and practical applications. By understanding the fundamental concepts, characteristics, and functions of various linear ICs, students and engineers can develop a solid foundation in analog electronics. Regular revision of these 2-mark questions, along with practical circuit analysis, will enhance your confidence and competence in this essential area of electronics.

Disclaimer: This article is intended for educational purposes and covers commonly asked 2-mark questions on linear integrated circuits. For detailed understanding, refer to standard textbooks and practical circuit manuals.

### Linear Integrated Circuits Important Questions 2 Marks: A Comprehensive Guide

Linear integrated circuits (ICs) form the backbone of analog electronics, enabling functions such as amplification, filtering, oscillation, and signal processing. For students and professionals preparing for examinations or practical applications, understanding the key questions related to linear ICs is essential. In this detailed review, we will explore the most important 2-mark questions, their concepts, and their significance in the realm of linear integrated circuits.

## Understanding Linear Integrated Circuits: An Introduction

Linear integrated circuits are specialized electronic circuits that operate in the linear region of their characteristic curves, meaning their output signal is directly proportional to their input. Unlike digital ICs, which operate in discrete states (0 and 1), linear ICs handle continuous signals, making them vital for analog signal processing.

Key Characteristics of Linear ICs:

- Operate in the linear region of transistor operation.
- Provide amplification, filtering, and oscillation functionalities.
- Comprise various components like operational amplifiers, voltage regulators, and comparators.

## Fundamental Types of Linear ICs

Understanding the types of linear ICs is fundamental to grasping their applications and answering related questions.

Major Categories Include:

- Operational Amplifiers (Op-Amps): Versatile components used for amplification, filtering, and mathematical operations.
- Voltage Regulators: Maintain a constant output voltage despite variations in input voltage or load conditions.
- Comparators: Used for comparison operations, outputting a high or low signal depending on input voltages.
- Active Filters: Used for filtering signals in analog circuits.
- Precision Rectifiers and Peak Detectors: For accurate rectification and signal peak detection.

## Common Important Questions (2 Marks) in Linear ICs

In exams, concise, precise answers are required for 2-mark questions. These questions typically test fundamental concepts, definitions, and basic operations of linear ICs.

- What is an Operational Amplifier?

An operational amplifier (op-amp) is a high-gain voltage amplifier with differential input and usually a single-ended output. Its primary function is to amplify the voltage difference between its two inputs.

Key Features:

- High input impedance.
- Low output impedance.
- Very high voltage gain (typically  $10^5$  to  $10^7$ ).
- Used in various applications like amplification, filtering, and mathematical operations.

- What is the Voltage Gain of an Op-Amp?

The voltage gain ( $A_v$ ) of an op-amp is the ratio of the output voltage to the input voltage difference.

Expression:

$$A_v = \frac{V_{out}}{V_{in}}$$

In ideal conditions, the open-loop voltage gain is very high, often exceeding 100,000.

- Define Common Mode and Differential Mode in Op-Amps
- Common Mode Voltage: The voltage applied equally to both inputs.
- Differential Mode Voltage: The voltage difference between the two inputs.

Common Mode Rejection Ratio (CMRR) measures the ability of an op-amp to reject common-mode signals.

- What is the Function of a Voltage Regulator IC?

A voltage regulator IC maintains a constant output voltage despite variations in input voltage or load current. It ensures the stability of electronic circuits.

Types:

- Linear Voltage Regulators: Drop excess voltage as heat.
- Switching Regulators: More efficient, using switching techniques.
- Explain the Working of a Voltage Regulator IC

Linear voltage regulators work by comparing the output voltage with a reference voltage and adjusting the pass element (transistor) to maintain a steady output.

Key Point: They provide a smooth, stable output voltage suitable for sensitive analog circuitry.

### - What is a Comparator?

A comparator is a device that compares two voltages and outputs a digital signal indicating which input is higher.

Operation:

- Output is high if the non-inverting input (+) exceeds the inverting input (?).
- Output is low if the inverting input exceeds the non-inverting input.

### - Difference Between an Op-Amp and a Comparator

| Aspect   | Op-Amp                        | Comparator                               |
|----------|-------------------------------|------------------------------------------|
| Function | Used in linear applications   | Used for decision-making, digital output |
| Output   | Can be in linear region       | Saturates to maximum or minimum voltage  |
| Feedback | Usually with feedback network | No feedback or open-loop                 |

### - What is the Role of an Operational Amplifier in Filtering?

Op-amps are used to design active filters?low-pass, high-pass, band-pass, and band-stop filters?by incorporating resistors and capacitors.

Advantages:

- Improved gain and selectivity.
- No need for large inductors.

### - Explain the Concept of Slew Rate in Op-Amps

Slew rate is the maximum rate at which the output voltage can change, usually expressed in V/?s. It limits the speed at which an op-amp can respond to rapid input changes.



Implication: A low slew rate causes distortion in high-frequency signals.

- What is the Purpose of a Voltage Regulator IC in Power Supply Circuits?

It provides a steady output voltage, ensuring consistent operation of electronic devices, and protects circuits from voltage fluctuations.

## Applications and Practical Significance of Important Questions

Understanding these fundamental questions is crucial because they form the basis of designing and troubleshooting analog electronic circuits. For example:

- Operational Amplifiers: Knowledge of their characteristics helps in designing amplifiers, oscillators, and filters.
- Voltage Regulators: Ensuring power supply stability is vital for sensitive components like microprocessors and sensors.
- Comparators: Used in zero-crossing detectors, pulse width modulation, and over-voltage protection circuits.

## Additional Important 2-Mark Questions in Linear ICs

Beyond the basics, some questions delve into specific ICs and their parameters:

- What is the Pin Configuration of a Typical Operational Amplifier?

Most op-amps (like LM741) have:

- Pin 1: Offset Null
- Pin 2: Inverting Input
- Pin 3: Non-inverting Input
- Pin 4: V<sub>-</sub> (Negative power supply)
- Pin 5: Offset Null
- Pin 6: Output
- Pin 7: V<sub>+</sub> (Positive power supply)
- Pin 8: No connection or used for offset null

- What is the Role of a Zener Diode in Voltage Regulation?

In voltage regulators, Zener diodes are used as voltage references because they maintain a constant voltage across them when reverse-biased beyond their breakdown voltage.

- Define Bandwidth in an Operational Amplifier

Bandwidth is the range of frequencies over which the op-amp can operate effectively without significant gain reduction. It is inversely related to gain (gain-bandwidth product).

- What is the Significance of Input Bias Current in Op-Amps?

Input bias current is the small DC current required at the input terminals of an op-amp for proper operation. It affects accuracy in high-impedance circuits.

- Explain the Concept of Voltage Follower (Buffer Amplifier)

A voltage follower circuit, using an op-amp, provides high input impedance, low output impedance, and unity gain, used for impedance matching.

## Summary and Final Thoughts

This extensive review of linear integrated circuits important questions 2 marks emphasizes the importance of understanding core concepts such as operational amplifiers, voltage regulators, comparators, and their applications. Mastery of these fundamental questions enables students and practitioners to:

- Grasp the basic working principles of linear ICs.
- Prepare effectively for exams with concise, accurate answers.
- Design and troubleshoot analog circuits efficiently.
- Appreciate the real-world applications of linear ICs in power supplies, instrumentation, and signal processing.

### Key Takeaways:

- Always understand the basic definitions and functions.

- Focus on the characteristics and pin configurations of ICs.
- Recognize the practical applications of each IC type.
- Be prepared to answer questions related to circuit operation, parameters, and applications succinctly.

By internalizing these essential questions and their answers, learners can build a strong foundation in linear integrated circuits, paving the way for advanced studies and professional competence in electronics engineering.

## End of Content

**QuestionAnswer** What is a linear integrated circuit? A linear integrated circuit is a type of IC that produces output signals proportional to its input, used for amplification and signal processing. Name a common application of linear ICs. Operational amplifiers are common linear ICs used in amplification, filtering, and mathematical operations. What is the primary function of an op-amp in linear ICs? An op-amp amplifies the voltage difference between its two inputs and is used in various linear applications. What are the advantages of using linear integrated circuits? They provide high precision, stability, and are easy to use in various analog signal processing applications. Name a key parameter of linear ICs that determines their performance. Gain bandwidth product is a key parameter that indicates the frequency response of linear ICs like operational amplifiers. Why are linear ICs preferred over discrete components in certain applications? They offer compact size, ease of integration, consistent performance, and reduce circuit complexity. What is the typical power supply voltage range for linear ICs? Most linear ICs operate within a voltage range of  $\pm 5V$  to  $\pm 15V$ , depending on the specific device.

**Related keywords:** linear integrated circuits, important questions, 2 marks, op-amp circuits, applications of ICs, IC advantages, IC types, voltage regulators, amplifier configurations, IC pin configurations

## LINEAR INTEGRATED CIRCUITS NOTES

### Linear Integrated Circuits Notes

Linear integrated circuits (ICs) are fundamental components in the field of electronics, playing a crucial role in signal processing, amplification, and various other analog applications. These circuits are designed to operate over a continuous range of input signals, making them essential for tasks that require precise and reliable analog operation. Whether you are a student, an engineer, or a hobbyist, understanding the basics and advanced concepts of linear ICs is vital for designing

efficient electronic systems.

In this comprehensive guide, we will delve into the core concepts of linear integrated circuits, their types, applications, working principles, and important parameters. This article aims to serve as an in-depth resource, optimized for search engines to help you find relevant information quickly and efficiently.

## What Are Linear Integrated Circuits?

Linear integrated circuits are a category of ICs that operate within the linear or analog domain. Unlike digital ICs, which work with discrete binary states (0s and 1s), linear ICs handle continuous signals, allowing for amplification, filtering, and other analog functions.

Definition:

A linear IC is an integrated circuit that produces an output directly proportional to its input signal, maintaining a linear relationship within a specified range.

Key Characteristics:

- Operate in the analog domain.
- Provide voltage, current, or power amplification.
- Offer high input impedance and low output impedance.
- Designed for precise signal processing.

Common Examples of Linear ICs:

- Operational Amplifiers (Op-Amps)
- Voltage Regulators
- Analog Multipliers
- Comparators
- Differential Amplifiers

## Importance of Linear Integrated Circuits

Linear ICs are vital in various applications because of their ability to accurately process analog signals. They are used in:

- Audio and radio frequency amplification
- Signal filtering and conditioning
- Voltage regulation in power supplies
- Sensor signal processing
- Measurement and instrumentation systems

Their versatility and precision make them indispensable in both consumer electronics and industrial automation.

## Types of Linear Integrated Circuits

Linear ICs can be broadly categorized based on their functions:

### 1. Operational Amplifiers (Op-Amps)

Op-amps are versatile linear ICs used for amplification, filtering, and mathematical operations.

### 2. Voltage Regulators

These ICs maintain a constant output voltage despite variations in input voltage or load conditions.

### 3. Comparators

Comparators compare two voltages and output a digital signal indicating which is higher.

### 4. Instrumentation Amplifiers

Designed for precise low-level signal measurement, often used in medical and industrial instrumentation.

### 5. Analog Multipliers and Dividers

Used to perform mathematical operations on analog signals.

### 6. Diode and Transistor Arrays

Integrated diode and transistor configurations for specific functions like rectification or switching.

## Working Principles of Linear ICs

Understanding how linear ICs operate is essential for their effective application.

## Operational Amplifiers (Op-Amps)

- Core concept: An op-amp amplifies the voltage difference between its two input terminals (inverting and non-inverting).
- Ideal characteristics: Infinite open-loop gain, infinite input impedance, zero output impedance.
- Real-world configuration: Usually used with external resistors and capacitors to set gain and frequency response.

## Voltage Regulators

- Basic operation: Uses a reference voltage and feedback mechanism to maintain a steady output voltage.
- Types: Linear regulators (dropout voltage) and switching regulators.

## Comparators

- Functionality: Compares two input voltages and switches its output to high or low state.
- Application: Zero-crossing detectors, threshold detection.

## Important Parameters of Linear ICs

When selecting a linear IC for a specific application, several parameters must be considered:

- Gain (A): Amplification factor of the IC.
- Input impedance ( $Z_{in}$ ): Resistance to input signals, ideally very high.
- Output impedance ( $Z_{out}$ ): Resistance at the output terminal, ideally very low.
- Bandwidth: Range of frequencies over which the IC operates effectively.
- Power supply voltage: Voltage range required for operation.
- Total Harmonic Distortion (THD): Measures the fidelity of amplification.
- Offset voltage: Small voltage difference at the input leading to output error.
- Slew rate: Max rate of change of output voltage, affecting high-frequency response.

## Applications of Linear Integrated Circuits

Linear ICs are integral to numerous electronic systems and devices:

### 1. Audio Amplifiers

- Used to amplify audio signals with high fidelity.
- Essential in home theater systems, microphones, and musical instrument amplifiers.

## 2. Signal Conditioning

- Amplify or filter signals from sensors before digitization.
- Used in measurement systems, medical devices, and industrial controls.

## 3. Voltage Regulation

- Provide stable power supply voltages.
- Critical in consumer electronics, computers, and communication equipment.

## 4. Oscillators and Waveform Generators

- Generate sinusoidal or square wave signals for communication and testing.

## 5. Instrumentation and Measurement

- Enable precise measurement of physical quantities like temperature, pressure, and light.

## Design Considerations for Linear ICs

When designing circuits with linear ICs, consider:

- Power supply compatibility: Ensure the IC operates within the specified voltage range.
- Thermal management: Use heat sinks or proper PCB layout to prevent overheating.
- Input/output loading: Match load impedance to prevent distortion.
- Feedback network: Proper resistor/capacitor selection for stability and desired gain.
- Noise performance: Choose ICs with low noise specifications for sensitive applications.

## Advantages and Disadvantages of Linear ICs

Advantages:

- High precision and accuracy.
- Simple circuit design.
- Good linearity and fidelity.
- Suitable for low-frequency applications.

Disadvantages:

- Limited efficiency, especially in voltage regulators.
- Larger size compared to modern switching circuits.
- Heat dissipation issues at high power levels.
- Lower bandwidth compared to some digital/analog converters.

## Summary and Conclusion

Linear integrated circuits are essential building blocks in modern electronics, enabling precise and reliable analog signal processing. From operational amplifiers to voltage regulators, these ICs serve a wide array of applications across consumer, industrial, and scientific domains. Understanding their working principles, parameters, and design considerations is crucial for engineers and students aiming to develop efficient electronic systems.

By mastering the concepts outlined in these notes, you can confidently approach the design, analysis, and troubleshooting of circuits involving linear ICs. Whether you're designing an audio amplifier, a sensor interface, or a power supply, a solid grasp of linear integrated circuits will significantly enhance your ability to create innovative and effective electronic solutions.

For further study, explore datasheets of popular linear ICs, experiment with practical circuits, and stay updated on advancements in analog integrated circuit technology.

**Keywords:** Linear integrated circuits, operational amplifier notes, voltage regulator principles, analog IC applications, linear circuit design, electronic circuit notes, signal amplification, instrumentation amplifiers.

Linear Integrated Circuits Notes are fundamental resources for students, engineers, and professionals working in the field of electronics. These notes provide a comprehensive understanding of the principles, applications, and characteristics of linear ICs, which are crucial components in analog signal processing, amplification, filtering, and many other electronic systems. With the rapid advancement of electronics technology, a solid grasp of linear integrated circuits remains essential for designing reliable and efficient electronic devices.

## Introduction to Linear Integrated Circuits



Linear integrated circuits (ICs) are a class of ICs that operate in the linear region of their characteristics, meaning their output is directly proportional to their input signal within specified limits. Unlike digital ICs, which operate with discrete high and low states, linear ICs process continuous signals, making them vital in analog electronics.

### What are Linear Integrated Circuits?

Linear ICs are designed to perform functions such as amplification, filtering, oscillation, and voltage regulation. They typically consist of multiple transistors, resistors, capacitors, and sometimes diodes, all integrated on a single chip to perform a specific analog function.

### Importance of Linear ICs

- Amplification: Used in audio systems, instrumentation, and communication systems.
- Filtering: Essential in signal processing to remove unwanted noise or frequencies.
- Voltage Regulation: Maintains steady output voltage in power supplies.
- Oscillation: Generates clock signals or carrier waves in communication systems.

## Types of Linear Integrated Circuits

Linear ICs can be broadly classified based on their functions. Understanding these categories helps in selecting the appropriate IC for a specific application.

### - Operational Amplifiers (Op-Amps)

Op-amps are versatile, high-gain voltage amplifiers with differential inputs and high impedance. They are the building blocks of many linear circuits.

### - Voltage Regulators

These ICs maintain a constant output voltage despite variations in input voltage or load current. They include:

- Series Regulators
- Shunt Regulators

- Comparators

Used to compare two voltages and output a digital signal indicating which is higher.

- Instrumentation Amplifiers

Designed for precise low-level signal amplification, often used in medical instruments and measurement systems.

- Special Function ICs

Including timers, waveform generators, and voltage reference ICs.

## **Operational Amplifiers: Features and Applications**

Operational amplifiers are perhaps the most widely used linear ICs. Their features and versatile applications make them indispensable in analog circuit design.

### **Features of Operational Amplifiers**

- Very high voltage gain ( $>10^5$ )
- High input impedance
- Low output impedance
- Wide bandwidth
- Differential inputs
- High common-mode rejection ratio (CMRR)
- Low offset voltage

### **Applications of Operational Amplifiers**

- Amplifiers: Voltage, current, transimpedance
- Filters: Active low-pass, high-pass, band-pass
- Oscillators: Sine wave generators
- Comparators: Zero-crossing detectors
- Integrators and Differentiators: Signal processing functions
- Voltage followers and Buffer Amplifiers

## Advantages and Limitations

Pros:

- High gain and linearity
- Flexibility in circuit design
- Compact integration

Cons:

- Limited bandwidth at high gains
- Offset voltages can affect precision
- Power consumption considerations

## Voltage Regulators: Types and Working Principles

Voltage regulators are crucial in power supply circuits, ensuring stable voltage delivery to sensitive electronic components.

### Types of Voltage Regulators

- Linear Voltage Regulators: Use pass transistors and references to maintain voltage.
- Switching Voltage Regulators: More efficient, switch modes for regulation.

### Linear Voltage Regulator ICs

- Simple design
- Low noise output
- Suitable for low to moderate power applications

### Features of Voltage Regulator ICs

- Fixed or adjustable output voltage
- Thermal protection
- Short-circuit protection
- Output current ratings

## Applications

- Power supplies for analog and digital circuits
- Battery chargers
- Voltage stabilization in sensitive equipment

## Pros and Cons

Pros:

- Simplicity and reliability
- Low output noise
- Cost-effective for low-power applications

Cons:

- Inefficient for high power dissipation
- Generates heat, requiring heat sinks
- Limited efficiency compared to switching regulators

## Operational Principles of Linear ICs

Understanding the working principles of linear ICs is essential for designing and troubleshooting electronic circuits.

Amplification in Op-Amps

- Based on differential input voltage
- High gain amplifies small input signals
- Negative feedback used to control gain and stabilize operation

Voltage Regulation

- Uses a reference voltage and pass element
- Adjusts the pass element current to maintain steady output

## Filtering and Oscillation

- Active filters employ op-amps to achieve desired frequency responses
- Oscillators utilize feedback networks to generate periodic waveforms

## Design Considerations and Parameters

When working with linear ICs, several parameters influence circuit performance.

### Key Parameters

- Gain-bandwidth product: Determines frequency response
- Input/output impedance: Affects signal transfer
- Slew rate: Rate of change of output voltage
- Offset voltage: Small voltage difference at input that causes output offset
- Power dissipation: Heat generated within ICs
- Temperature stability: Ensures consistent operation over temperature ranges

### Design Tips

- Use negative feedback to stabilize gain
- Select ICs with appropriate voltage and current ratings
- Include compensation networks to prevent oscillations
- Adequately heat sink power devices

## Applications of Linear Integrated Circuits

Linear ICs are employed across a wide array of applications in modern electronics.

### Audio Equipment

- Amplifiers for sound systems
- Equalizers and tone controls

### Measurement and Instrumentation

- Signal conditioning
- Data acquisition systems

### Communication Systems

- RF amplifiers
- Modulators and demodulators

### Power Management

- Voltage regulators
- Battery management systems

### Medical Electronics

- Signal amplifiers in ECG, EEG devices

## Advantages and Disadvantages of Linear ICs

### Advantages

- High accuracy and stability: Suitable for precision applications
- Low noise: Essential in audio and measurement systems
- Simple design and implementation: Easier to troubleshoot
- Compact and integrated: Multiple functions on a single chip

### Disadvantages

- Limited efficiency: Especially in power regulation
- Heat dissipation: Due to linear operation
- Limited bandwidth at high gains
- Cost: High-precision ICs can be expensive

## Summary and Future Trends

Linear Integrated Circuits Notes serve as comprehensive guides to understanding the core

principles, types, and applications of these vital components. They emphasize the importance of mastering the operational characteristics, design considerations, and practical applications of linear ICs in modern electronics.

Looking ahead, advancements in materials and fabrication techniques continue to improve the performance of linear ICs. Innovations such as low-noise op-amps, ultra-low power voltage regulators, and high-frequency linear ICs are expanding the scope of applications. Moreover, integration with digital systems and the development of mixed-signal ICs are transforming the landscape of analog electronics.

In conclusion, a thorough understanding of linear integrated circuits, supported by well-structured notes, remains indispensable for anyone involved in designing, analyzing, or troubleshooting analog electronic systems. They bridge fundamental theory with practical implementation, enabling the creation of efficient, reliable, and innovative electronic devices.

**Question** What are linear integrated circuits and their main applications? Linear integrated circuits are electronic devices designed to operate in the linear region, providing amplification, buffering, or voltage regulation. They are widely used in audio amplification, signal processing, voltage regulators, and analog signal conditioning. What are the common types of linear integrated circuits? Common types include operational amplifiers (op-amps), voltage regulators, comparators, and buffer amplifiers, each serving specific functions in analog circuit design. How does an operational amplifier work in linear integrated circuits? An operational amplifier amplifies the voltage difference between its two inputs, providing high gain and used in various linear applications such as filtering, amplification, and mathematical operations. What are the key parameters to consider in linear IC notes? Important parameters include gain bandwidth product, slew rate, input and output impedance, offset voltage, and power supply requirements, which influence the performance of linear ICs. How do voltage regulators in linear ICs function? Linear voltage regulators maintain a constant output voltage by dissipating excess voltage as heat, providing stable power supply voltages in electronic circuits. What are the advantages and disadvantages of linear integrated circuits? Advantages include simplicity, low noise, and good linearity. Disadvantages involve lower efficiency, heat dissipation issues, and limited voltage regulation capabilities compared to switching regulators. What is the significance of the slew rate in linear ICs? The slew rate indicates how quickly an op-amp can respond to rapid changes in input voltage, affecting the circuit's ability to accurately reproduce fast signal transitions. How can I prepare effectively using notes on linear integrated circuits? Focus on understanding circuit configurations, key parameters, and applications. Practice solving problems and reviewing real-world applications to reinforce theoretical concepts. Are there any recent trends in linear integrated circuit technology? Yes, recent trends include the development of low-power and high-precision op-amps, integrated power management solutions, and advancements in low-noise amplifiers for sensitive applications like medical devices and communications.

**Related keywords:** linear amplifier, op-amp, voltage regulator, IC characteristics, transistor models, analog circuits, signal processing, feedback systems, biasing techniques, circuit design

**Read the full article online:** [Linear Integrated Circuits Notes](#)

## viva questions from op amp

### Viva Questions from Op Amp

Operational Amplifiers (Op Amps) are fundamental components in analog electronics, widely used in various circuits such as amplifiers, filters, oscillators, and more. Due to their significance, understanding the common viva questions related to Op Amps is essential for students and professionals preparing for technical interviews, exams, or lab assessments. This article provides a comprehensive overview of frequently asked viva questions from Op Amps, covering basic concepts, characteristics, configurations, and troubleshooting tips to prepare you thoroughly.

## Introduction to Operational Amplifiers

Operational Amplifiers are high-gain electronic voltage amplifiers with differential inputs and a single-ended output. They are designed to perform mathematical operations such as addition, subtraction, integration, and differentiation.

### What is an Op Amp?

- An Op Amp is a voltage amplifier with very high gain (typically  $10^5$  to  $10^7$ ).
- It has two inputs: inverting (-) and non-inverting (+).
- It produces an output voltage proportional to the difference between the voltages applied at its input terminals.

### Basic Characteristics of an Op Amp

- High Voltage Gain
- High Input Impedance
- Low Output Impedance
- Very high Common Mode Rejection Ratio (CMRR)
- Wide Bandwidth



## Common Viva Questions on Op Amp

Below are some frequently asked viva questions along with their answers, which are crucial for understanding and explaining the working and applications of Op Amps.

### Basic Conceptual Questions

**- Q1: What is an operational amplifier?**

An operational amplifier is a high-gain electronic amplifier designed to perform mathematical operations such as addition, subtraction, integration, and differentiation. It has two input terminals—the inverting (-) and non-inverting (+)—and one output terminal.

**- Q2: What are the ideal characteristics of an Op Amp?**

In an ideal case, an Op Amp exhibits:

- Infinite open-loop gain
- Infinite input impedance
- Zero output impedance
- Infinite bandwidth
- Zero input bias current
- Zero noise

**- Q3: What is the difference between an ideal and a real Op Amp?**

An ideal Op Amp has infinite gain, infinite input impedance, and zero output impedance. A real Op Amp has finite gain (though very high), finite input impedance, and non-zero output impedance, along with bandwidth limitations and input bias currents.

### Operational Principles and Working

**- Q4: How does an Op Amp work in a voltage follower configuration?**

In a voltage follower (buffer) configuration, the output is directly connected to the inverting input, and the input signal is applied to the non-inverting input. The Op Amp maintains its output voltage equal to the input voltage, providing high input impedance and low output impedance.

**- Q5: Explain the concept of negative feedback in an op amp circuit.**

Negative feedback involves feeding a portion of the output back to the inverting input. This stabilizes the gain, improves linearity, reduces distortion, and increases bandwidth, making the circuit more predictable and stable.

## Configurations and Applications

### - Q6: What are the common configurations of an Op Amp?

Common configurations include:

- Voltage follower (buffer)
- Inverting amplifier
- Non-inverting amplifier
- Adders
- Differential amplifiers
- Integrator
- Differentiator

### - Q7: Explain the working of an inverting amplifier using an Op Amp.

In an inverting amplifier, the input signal is applied to the inverting terminal through a resistor, while the non-inverting terminal is grounded. The feedback resistor connects the output to the inverting terminal. The circuit provides an amplified output with a phase inversion, with gain determined by the ratio of the feedback resistor to the input resistor.

## Parameters and Performance

### - Q8: What is the gain of an op amp?

The open-loop gain (AOL) of an Op Amp is the gain without any feedback, typically very high ( $10^5$  to  $10^7$ ). In closed-loop configurations, the gain is set by the external resistors or components.

### - Q9: What is bandwidth, and how does it relate to an Op Amp?

Bandwidth refers to the frequency range over which the Op Amp can operate effectively. As the gain increases, bandwidth decreases (gain-bandwidth product remains constant). High-frequency response is limited by internal compensation and parasitic effects.

### - Q10: Define input offset voltage and its effect.

Input offset voltage is the differential DC voltage that must be applied between the inputs to make the output zero. It causes inaccuracies in the output, especially in high-gain applications.

## Troubleshooting and Practical Considerations

### - Q11: What are common causes of op amp failure?

Common causes include exceeding maximum ratings (voltage, current), thermal runaway, improper power supply, and input/output shorts.

**- Q12: How can you prevent saturation in Op Amp circuits?**

By limiting input voltage ranges, using negative feedback, and ensuring the output is within the supply voltage limits.

**- Q13: What is the importance of power supply in an Op Amp?**

The power supply voltage determines the maximum and minimum output voltage swing. Proper and stable power supplies are essential for correct operation and minimizing distortion.

## Advanced Viva Questions from Op Amp

For more experienced candidates or advanced courses, here are some challenging viva questions:

**- Q14: Explain the concept of slew rate in an Op Amp.**

Slew rate is the maximum rate of change of the output voltage per unit time ( $V/\mu s$ ). It limits the speed at which the Op Amp can respond to rapid input changes, affecting high-frequency applications.

**- Q15: Describe the frequency response of an Op Amp and how it affects circuit design.**

Op Amps have a dominant pole that causes gain to decrease with frequency. Compensation techniques are used to extend bandwidth and stability in high-frequency circuits.

**- Q16: What is common-mode rejection ratio (CMRR) and why is it important?**

CMRR measures the ability of the Op Amp to reject common-mode signals at both inputs. A high CMRR is crucial for accurate differential measurements and noise immunity.

## Conclusion

Understanding viva questions from Op Amps is vital for mastering analog circuit design and troubleshooting. Preparing answers to these questions not only helps in exams but also enhances practical knowledge. Remember to grasp fundamental concepts, operational principles, configurations, and parameters, as well as practical considerations like biasing and stability. With thorough preparation, you can confidently tackle any viva or interview related to Op Amps and their applications.

Whether you're a student, researcher, or working engineer, keeping these questions and their answers in mind will serve as a solid foundation for your understanding of operational amplifiers and their pivotal role in electronics.

## Operational Amplifier (Op Amp) Viva Questions: An Expert Guide for Students and Professionals

### Introduction

In the realm of analog electronics, the Operational Amplifier (Op Amp) stands as one of the most fundamental and versatile components. Its widespread application across amplifiers, filters, oscillators, and various other circuit configurations makes it a core topic for students and engineers alike. Preparing for viva voce examinations or technical interviews requires a thorough understanding of the concepts, working principles, and applications of op amps.

This comprehensive guide aims to delve into the most commonly asked viva questions related to op amps, presenting detailed explanations, practical insights, and expert analyses. Whether you're a student gearing up for exams or a professional brushing up your knowledge, this article provides an authoritative resource to master op amp concepts confidently.

### What is an Operational Amplifier?

#### Definition and Basic Concept

An Operational Amplifier is a high-gain, direct-coupled electronic voltage amplifier with differential inputs and a single-ended output. It is designed to perform mathematical operations such as addition, subtraction, integration, and differentiation in analog form, which is why it's called an "operational" amplifier.

#### Key Characteristics

- High Voltage Gain: Typically in the order of  $10^5$  to  $10^7$ .
- High Input Impedance: Usually in megaohms, minimizing loading effects.
- Low Output Impedance: Ensures the amplifier can effectively drive loads.
- Differential Inputs: Two inputs?non-inverting (+) and inverting (?).

#### Commonly Asked Viva Questions on Op Amps

- What are the ideal characteristics of an op amp?

Ideal characteristics serve as a benchmark for analyzing and designing circuits. They include:

- Infinite Voltage Gain ( $A_v \rightarrow \infty$ ): Ensures that even a tiny difference in input voltage produces a significant output.
- Infinite Input Impedance ( $Z_{in} \rightarrow \infty$ ): No current flows into the input terminals, preventing loading.
- Zero Output Impedance ( $Z_{out} \rightarrow 0$ ): Allows the op amp to drive any load without voltage drop.
- Zero Input Offset Voltage: No inherent voltage difference needed to produce an output.
- Infinite Bandwidth: Operates effectively at all frequencies.
- Zero Noise: No additional noise introduced during operation.

In practice, real op amps approximate these ideal characteristics but never fully attain them.

- What are the practical limitations of an op amp?

While ideal characteristics are theoretical, practical op amps have limitations:

- Finite Gain: Typically around  $10^5$  to  $10^7$ .
- Input Bias Current: Small currents flowing into the input terminals, causing offset voltages.
- Input Offset Voltage: Small voltage required between inputs for zero output.
- Limited Bandwidth: Gain-bandwidth product limits high-frequency operation.
- Slew Rate: Maximum rate of change of output voltage, affecting response speed.
- Output Voltage Swing: Cannot reach supply rails exactly, especially in standard op amps.

Understanding these limitations is crucial for designing precise circuits and compensating for non-idealities.

- Explain the concept of differential amplifier configuration of an op amp.

Differential Amplifier:

An op amp inherently amplifies the difference between its two inputs. The differential amplifier configuration uses external resistors to set the gain for the difference between the voltages applied to the inverting and non-inverting inputs.

Working Principle:

The output voltage ( $V_{out}$ ) is proportional to the difference between the input voltages ( $V_+$  and  $V_-$ ), scaled by the gain:

$V_{out} = A_v (V_+ - V_-)$

$$V_{\text{out}} = A_d (V_{+} - V_{-})$$

]

where  $A_d$  is the differential gain, determined by the resistor network.

Applications:

- Signal subtraction
  - Noise reduction
  - Instrumentation amplifiers
- 
- What is the voltage gain of an op amp, and how is it determined?

Voltage Gain ( $A_v$ ):

It is the ratio of the output voltage to the differential input voltage:

[

$$A_v = \frac{V_{\text{out}}}{V_{\text{diff}}} = \frac{V_{\text{out}}}{V_{+} - V_{-}}$$

]

Determination:

In practical circuits, the gain is set by external resistors or feedback networks. For example, in an inverting amplifier:

[

$$A_v = - \frac{R_f}{R_{\text{in}}}$$

]

where  $R_f$  is the feedback resistor, and  $R_{\text{in}}$  is the input resistor.

Note:

The open-loop gain (without feedback) is extremely high ( $\sim 10^5$  to  $10^7$ ), but in feedback configurations, the gain is controlled and stabilized.

- Why is the concept of input offset voltage important?

Input Offset Voltage ( $V_{os}$ ):

A small voltage that must be applied between the inverting and non-inverting inputs to make the output zero in a balanced condition.

Importance:

- Causes erroneous output readings even with zero differential input.
- Affects precision measurements.
- Needs to be minimized or compensated for in sensitive applications.

Typical Values:

Range from microvolts to millivolts, depending on the op amp quality.

- Describe the various types of op amp configurations and their applications.

Common Configurations:

| Configuration           | Functionality                                                 | Application Examples                   |
|-------------------------|---------------------------------------------------------------|----------------------------------------|
| Inverting Amplifier     | Amplifies input signal with inversion                         | Audio amplification, signal processing |
| Non-inverting Amplifier | Amplifies input without inversion                             | Buffer circuits, voltage followers     |
| Voltage Follower        | Unity gain buffer, high input impedance, low output impedance | Impedance matching, buffering          |
| Differential Amplifier  | Amplifies the voltage difference between two inputs           | Instrumentation, sensor signals        |

| Summing Amplifier | Adds multiple input signals | Audio mixing, complex signal processing |

| Integrator | Produces an output proportional to the integral of input | Analog computers, waveform generation |

| Differentiator | Produces an output proportional to the rate of change of input | Edge detection, waveform shaping |

Understanding these configurations helps in designing circuits tailored to specific needs.

- What is the significance of the gain-bandwidth product?

Gain-Bandwidth Product (GBW):

A key parameter indicating the trade-off between gain and bandwidth in an op amp.

\[

$$\text{GBW} = A_v \times f_{\text{unity}}$$

\]

where:

- $A_v$ : Voltage gain
- $f_{\text{unity}}$ : Unity gain bandwidth frequency

Implication:

A higher GBW allows for higher gain at higher frequencies. In practical terms, as you increase the gain, the bandwidth over which the op amp can operate effectively decreases proportionally.

Design Consideration:

When designing high-frequency circuits, select op amps with sufficient GBW to meet the frequency and gain requirements.

- Explain the concept of slew rate and its impact on circuit performance.



### Slew Rate (SR):

The maximum rate at which the output voltage can change, usually expressed in volts per microsecond (V/μs).

\[

$$SR = \frac{dV_{out}}{dt}$$

\]

### Impact:

- Limited Slew Rate causes distortion when amplifying rapidly changing signals, such as square waves or pulses.
- If the input signal changes faster than the op amp's SR can handle, the output will lag or distort the waveform.

### Practical Example:

For a square wave with a high frequency, a low slew rate results in rounded edges instead of sharp transitions.

### Importance:

Choosing an op amp with an appropriate slew rate is essential for high-speed and high-frequency applications.

- How does feedback influence the operation of an op amp circuit?

### Feedback:

Connecting a portion of the output back to the input.

- Negative Feedback:

Stabilizes gain, reduces distortion, improves bandwidth, and increases input impedance.

- Positive Feedback:

Leads to regenerative behavior, used in oscillators and comparators.

Effects of Negative Feedback:

- Controls gain: Sets the overall gain via external resistors.
- Reduces distortion: Ensures linear operation.
- Improves bandwidth: Extends frequency response.
- Increases stability: Minimizes drift and variations.

Design Tip:

Most practical op amp circuits employ negative feedback to achieve desired linear amplification.

- What are some common applications of op amps?

Op amps are integral to a multitude of electronic systems:

- Amplifiers: Audio, instrumentation, and sensor signals.
- Filters: Active low-pass, high-pass, band-pass, and band-stop filters.
- Oscillators: sine wave, square wave generators.
- Comparators: Zero-crossing detectors.
- Integrators and Differentiators: Waveform shaping, analog computers.
- Voltage Followers: Buffering and impedance matching.
- Analog Computations: Addition, subtraction, multiplication, and division circuits.

Practical Tips for Viva Preparation

- Understand core concepts thoroughly: Differentiating between ideal and real characteristics.
- Practice circuit analysis: Be comfortable with common configurations.
- Memorize key formulas: Gain, bandwidth, slew rate, etc.
- Relate theory to real-world applications: Demonstrate practical understanding.
- Prepare for "why"

**Question** What is an operational amplifier (op-amp)? An operational amplifier is a high-gain voltage amplifier with differential inputs and usually a single-ended output, used for

various analog signal processing tasks. What are the typical applications of op-amps? Op-amps are used in amplifiers, filters, oscillators, voltage followers, integrators, differentiators, and in many signal conditioning circuits. Explain the concept of open-loop and closed-loop configurations in op-amps. Open-loop configuration has no feedback and provides very high gain, while closed-loop configuration uses feedback to control gain, improve stability, and reduce distortion. What is the significance of the input bias current in an op-amp? Input bias current is the small current required at the input terminals of the op-amp; it can cause errors in high-impedance circuits and must be considered during circuit design. Define the concept of virtual short in op-amp analysis. A virtual short is a condition where the voltage difference between the inverting and non-inverting inputs is zero in an ideal op-amp with negative feedback, meaning both inputs are at the same voltage but no current flows between them.

**Related keywords:** op amp questions, op amp basics, op amp circuits, op amp applications, operational amplifier theory, op amp troubleshooting, op amp comparison, op amp datasheet, op amp parameters, op amp design

**Read the full article online:** [viva questions from op amp](#)

## operational amplifiers and linear integrated circuits

### Operational Amplifiers and Linear Integrated Circuits

**Operational amplifiers and linear integrated circuits** are fundamental components in modern electronics, playing vital roles in signal processing, control systems, audio amplification, and many other applications. Their versatility, precision, and ease of integration have made them indispensable in both consumer electronics and industrial systems. This comprehensive guide explores the principles, types, applications, and characteristics of operational amplifiers (op-amps) and linear integrated circuits, providing a detailed understanding suitable for students, engineers, and electronics enthusiasts.

### Understanding Operational Amplifiers

## What is an Operational Amplifier?

An operational amplifier, commonly known as an op-amp, is a high-gain voltage amplifier with differential input and a single-ended output. It is designed to perform mathematical operations such as addition, subtraction, integration, and differentiation, hence the name "operational."

### Basic Structure and Functionality

- Input Terminals:
- Inverting Input (-): The signal applied here is inverted at the output.
- Non-inverting Input (+): The signal applied here is in phase with the output.
- Output Terminal: Provides the amplified output signal.
- Power Supply Pins: Usually dual supplies (+V and -V) provide the necessary power for operation.

### Ideal versus Real Op-Amps

| Characteristic   | Ideal Op-Amp | Real Op-Amp                      |
|------------------|--------------|----------------------------------|
| Input Impedance  | Infinite     | Very high but finite             |
| Output Impedance | Zero         | Low but finite                   |
| Voltage Gain     | Infinite     | Very high ( $10^5$ to $10^7$ )   |
| Bandwidth        | Infinite     | Limited (Gain-Bandwidth Product) |
| Offset Voltage   | Zero         | Small but non-zero               |

### Types of Operational Amplifiers

Operational amplifiers are classified based on their characteristics and applications:

#### General-Purpose Op-Amps

- Designed for a wide range of applications.
- Examples: LM741, TL071.

## Precision Op-Amps

- Offer low offset voltage, low bias current, and high stability.
- Suitable for measurement and instrumentation.
- Examples: OP07, ADA4528.

## High-Speed and Wide Bandwidth Op-Amps

- Designed for high-frequency applications.
- Examples: AD8000, LMH6702.

## Rail-to-Rail Op-Amps

- Capable of outputting voltages close to the supply rails.
- Useful in battery-powered and low-voltage systems.
- Examples: MCP6002, TLV2371.

## Key Parameters of Operational Amplifiers

Understanding the critical parameters helps in selecting the right op-amp for specific applications:

- Gain-Bandwidth Product (GBP): Determines the frequency range for a given gain.
- Slew Rate: The maximum rate of change of output voltage, affecting high-speed response.
- Input Offset Voltage: Small voltage difference required between inputs to produce zero output.
- Input Bias Current: The DC current required at input terminals.
- Input Impedance: Resistance faced by the input signal.
- Output Impedance: Resistance seen at the output terminal.

## Linear Integrated Circuits: An Overview

### Definition and Role

Linear integrated circuits (ICs) are semiconductor devices designed to operate in the linear region of their transfer characteristics, maintaining proportionality between input and output signals. They encompass a wide range of functions, including amplifiers, voltage regulators, oscillators, and filters.

### Types of Linear ICs

- Amplifier ICs: Operational amplifiers, power amplifiers.
- Voltage Regulators: Fixed and adjustable regulators.
- Analog Signal Processing ICs: Filters, mixers, modulators.
- Data Conversion ICs: A/D and D/A converters.

## Applications of Operational Amplifiers and Linear ICs

### Signal Conditioning and Processing

- Amplification of weak signals.
- Filtering (active filters).
- Integration and differentiation in analog computers.

### Audio and Video Equipment

- Preamplifiers.
- Equalizers.
- Audio mixers.

### Measurement and Instrumentation

- Data acquisition systems.
- Sensors interfacing.
- Precision measurements.

### Control Systems

- Voltage regulators.
- Motor control circuits.
- Feedback control loops.

### Communication Systems

- Modulators and demodulators.
- Signal amplifiers in transceivers.

## Designing with Operational Amplifiers

### Basic Configurations

- Inverting Amplifier:
  - Provides a gain of  $-R_f/R_{in}$ .
  - Suitable for voltage inversion and buffering.
  
- Non-Inverting Amplifier:
  - Provides a gain of  $(1 + R_f/R_{in})$ .
  - Used when phase preservation is needed.
  
- Voltage Follower (Buffer):
  - Unity gain configuration.
  - Used for impedance matching.
  
- Comparator:
  - Converts analog signals into digital logic.

### Practical Design Considerations

- Power supply voltage limits.
- Input and output voltage ranges.
- Stability and frequency response.
- Noise performance.

### Linear ICs in Modern Electronics

## Advantages

- Compact size.
- Low power consumption.
- High reliability.
- Ease of integration into complex systems.

## Challenges

- Limited bandwidth in some applications.
- Non-idealities such as offset voltage and bias currents.
- Temperature sensitivity.

## Future Trends and Innovations

- Development of ultra-low power op-amps for portable devices.
- Integration of multiple functions into single ICs for miniaturization.
- Enhanced bandwidth and speed for high-frequency applications.
- Improved linearity and noise performance.

## Conclusion

Operational amplifiers and linear integrated circuits are cornerstones of analog electronics, enabling precise control, measurement, and signal processing across countless applications. Their versatility, combined with ongoing innovations, ensures their continued relevance in the evolving landscape of electronic devices and systems. Whether designing simple amplification circuits or complex control systems, understanding these components is essential for any electronics professional or enthusiast aiming to develop reliable and efficient electronic solutions.

## References

- Sedra, A. S., & Smith, K. C. (2014). Microelectronic Circuits. Oxford University Press.
- Boylestad, R., & Nashelsky, L. (2009). Electronic Devices and Circuit Theory. Pearson Education.
- Franco, S. (2014). Design with Operational Amplifiers and Analog Integrated Circuits. McGraw-Hill Education.
- Texas Instruments, Operational Amplifier Basics. [Online Resource]



- Analog Devices, Linear ICs Overview. [Online Resource]

By mastering the concepts and applications of operational amplifiers and linear integrated circuits, engineers and students can significantly enhance their ability to design and troubleshoot advanced electronic systems.

## Operational Amplifiers and Linear Integrated Circuits

In the realm of modern electronics, operational amplifiers (op-amps) and linear integrated circuits are foundational components that have revolutionized how engineers design and implement a vast array of analog systems. From audio processing and instrumentation to control systems and signal conditioning, these devices form the backbone of countless applications. To appreciate their significance fully, it's essential to explore their fundamental principles, design features, types, and practical applications.

## Understanding Operational Amplifiers: The Heart of Analog Signal Processing

### What is an Operational Amplifier?

An operational amplifier is a high-gain voltage amplifier designed to perform mathematical operations such as addition, subtraction, integration, and differentiation on input signals. Its fundamental architecture comprises multiple transistors, resistors, and sometimes capacitors, all integrated into a single chip to achieve high gain and versatility.

Operational amplifiers are characterized by their differential input, meaning they amplify the voltage difference between their two input terminals: the inverting input (marked as  $-$ ) and the non-inverting input (marked as  $+$ ). Their output then provides an amplified version of this difference, often subjected to external feedback to tailor their behavior.

### Basic Parameters and Characteristics

Several parameters define the performance and suitability of an op-amp for specific applications:

- Open-Loop Gain ( $A_{OL}$ ): Typically very high ( $10^5$  to  $10^7$ ), indicating that the op-amp amplifies the input differential voltage by a large factor when no feedback is applied.
- Input Impedance ( $Z_{in}$ ): Usually very high, often in the megaohms range, which minimizes loading on preceding stages.

- Output Impedance ( $Z_{out}$ ): Generally low, enabling the op-amp to drive loads effectively.
- Bandwidth: The frequency range over which the op-amp maintains a specified gain. High-gain op-amps tend to have limited bandwidth due to gain-bandwidth product constraints.
- Slew Rate: The maximum rate at which the output voltage can change, affecting the amplifier's response to rapidly changing signals.
- Input Offset Voltage: Small voltage differences that must be compensated for to ensure accurate amplification.
- Power Supply Requirements: Op-amps may operate from single or dual power supplies, influencing their input/output voltage ranges.

## Operational Amplifier Configurations

Operational amplifiers are used in numerous configurations, each suited to different functions:

- Voltage Follower (Buffer): Provides high input impedance and low output impedance, used to buffer signals without amplification.
- Inverting Amplifier: Produces an output that is inverted and scaled relative to the input, ideal for gain control.
- Non-Inverting Amplifier: Offers voltage amplification without phase inversion, suitable for impedance matching.
- Adder and Subtractor Circuits: Combine multiple signals or find their difference.
- Integrator and Differentiator: Perform mathematical integration or differentiation on input signals, critical in analog computational systems.

# Linear Integrated Circuits: The Building Blocks of Analog Design

## What Are Linear Integrated Circuits?

Linear integrated circuits encompass a broad class of monolithic devices designed to perform linear, or proportional, operations on electrical signals. Unlike digital circuits, which operate with discrete voltage levels, linear ICs process continuous signals, making them indispensable in analog signal processing, filtering, and regulation.

These ICs include op-amps, voltage regulators, voltage references, analog multipliers, and specialized function blocks. Their integrated nature ensures compactness, improved reliability, and ease of use compared to discrete component assemblies.

## Types and Categories of Linear ICs

Linear ICs can be categorized based on their function:

- Operational Amplifier ICs: The most prevalent, used for amplification, filtering, and mathematical operations.
- Voltage Regulator ICs: Provide stable voltage outputs despite variations in input voltage or load current, crucial for power supply design.
- Voltage Reference ICs: Offer precise and stable voltage levels for measurement and control applications.
- Analog Multipliers and Mixers: Enable multiplication or mixing of signals for modulation and demodulation.
- Active Filters: Incorporate op-amps and passive components to create filters with specific frequency responses.
- Instrumentation Amplifiers: Provide high gain with excellent common-mode rejection, used in measurement and sensor applications.

## Design and Integration of Linear ICs

Manufacturers utilize monolithic fabrication techniques, integrating multiple components onto a single silicon chip to produce linear ICs with predictable performance, minimal parasitics, and high stability. These integrated devices often include bias circuitry, compensation networks, and other auxiliary components internally, simplifying circuit design.

The design process involves optimizing parameters like bandwidth, noise performance, power consumption, and linearity, tailored to application-specific needs. Advanced linear ICs may incorporate temperature compensation, low offset voltages, and high slew rates to meet demanding specifications.

## Applications and Practical Considerations

### Common Applications of Operational Amplifiers

Operational amplifiers are incredibly versatile. Some typical applications include:

- Signal Conditioning: Amplifying or filtering sensor signals in instrumentation.
- Audio Equipment: Pre-amplifiers, equalizers, and tone controls.
- Control Systems: Feedback loops in motor controllers and process automation.
- Data Acquisition: Amplifying signals for analog-to-digital conversion.
- Mathematical Operations: Implementing integrations, differentiations, and summations in analog computers.

### Practical Design Tips and Challenges

When designing with op-amps and linear ICs, engineers must consider:

- Power Supply Compatibility: Ensure the IC can operate within the available supply voltages.

- Input and Output Voltage Ranges: Prevent input voltages from exceeding the acceptable common-mode range to avoid saturation or distortion.
- Stability and Compensation: Use frequency compensation techniques to prevent oscillations, especially in high-gain configurations.
- Noise and Distortion: Select low-noise op-amps for sensitive measurements; minimize distortion in high-fidelity audio applications.
- Thermal Management: High-power applications require proper heat sinking and thermal considerations.
- Component Tolerances: Use precision resistors and capacitors where accuracy is critical.

## Emerging Trends and Innovations

Recent advancements in linear IC technology include:

- Rail-to-Rail Op-Amps: Capable of input and output voltages close to the supply rails, expanding usability in low-voltage systems.
- Low-Noise Amplifiers: Designed for high-precision measurement and instrumentation.
- Integrated Filtering and Signal Processing: Combining multiple functions into single chips for compact, power-efficient designs.
- Smart Linear ICs: Incorporating digital control interfaces for adaptive operation.

## Conclusion: The Critical Role of Operational Amplifiers and Linear ICs

Operational amplifiers and linear integrated circuits are quintessential to modern analog electronics, enabling precise, stable, and flexible signal processing. Their continuous evolution ? driven by

demands for higher performance, lower power consumption, and greater integration ? underscores their enduring relevance.

Designers and engineers leverage these devices not just as passive components but as active, intelligent building blocks capable of complex operations. Whether in high-precision measurement systems, audio electronics, or power management, the thoughtful selection and application of op-amps and linear ICs can significantly influence system performance and reliability.

As technology advances, the integration of sophisticated features into linear ICs promises to unlock new possibilities, making them even more indispensable in the future landscape of electronics innovation.

**Question** What are the primary applications of operational amplifiers in electronic circuits? Operational amplifiers are widely used in signal conditioning, filtering, analog computation, voltage amplification, and as active elements in oscillators and comparators due to their high gain and versatility. How does negative feedback improve the performance of an operational amplifier circuit? Negative feedback reduces gain variability, improves linearity, bandwidth, and stability, and minimizes distortion and noise, leading to more accurate and reliable circuit performance. What are the key characteristics to consider when selecting an operational amplifier for a specific application? Important characteristics include bandwidth, gain-bandwidth product, input impedance, output impedance, slew rate, noise level, power supply requirements, and total harmonic distortion. Can you explain the difference between an ideal op-amp and a real-world operational amplifier? An ideal op-amp has infinite open-loop gain, infinite input impedance, zero output impedance, and zero noise. Real-world op-amps have finite gain, limited bandwidth, non-zero input/output impedance, and some noise, which must be considered in circuit design. What are linear integrated circuits, and how do they relate to operational amplifiers? Linear integrated circuits are ICs designed to perform linear functions such as amplification, filtering, and signal processing. Operational amplifiers are a fundamental type of linear IC used extensively in analog signal processing applications.

**Related keywords:** amplifier circuits, linear ICs, voltage amplifiers, current amplifiers, analog signal processing, differential amplifiers, op-amp configurations, feedback circuits, frequency response, noise analysis

**Read the full article online:** [Operational amplifiers and linear integrated circuits](#)

## Electronic circuit 1 salivahanan ce amplifier

**electronic circuit 1 salivahanan ce amplifier** is a fundamental project that introduces students

and electronics enthusiasts to the principles of amplification, circuit design, and practical implementation of electronic components. This amplifier serves as an essential building block in various electronic devices, from audio systems to communication equipment. Understanding its design, working, and applications provides a strong foundation for further exploration in analog electronics.

## Introduction to Salivahanan CE Amplifier

The Salivahanan CE (Common Emitter) amplifier is a popular configuration used to amplify voltage signals. Its widespread use in educational settings, especially in the first electronic circuit course, makes it an essential topic for students learning about transistor-based amplification.

This configuration involves a bipolar junction transistor (BJT) configured as a common emitter, which acts as the main amplifying component. The circuit's design emphasizes understanding biasing, load line analysis, and frequency response.

## Overview of Electronic Circuit 1 Salivahanan CE Amplifier

The primary purpose of the first electronic circuit involving the Salivahanan CE amplifier is to demonstrate the basic operation of a BJT amplifier, including:

- Biasing techniques to ensure the transistor operates in the active region.
- Voltage amplification of an AC input signal.
- Analysis of gain, input, and output impedance.
- Practical considerations like coupling, bypassing, and stabilization.

Typically, this circuit is built on a breadboard or PCB for educational purposes, allowing students to experiment and observe real-world behavior.

## Components Used in the Salivahanan CE Amplifier Circuit

Understanding the components involved is crucial for designing and troubleshooting the amplifier. The core components include:

### Bipolar Junction Transistor (BJT)

- Usually a 2N2222 or BC547 transistor.
- Acts as the active device amplifying the input signal.

## Resistors

- Biasing resistors (e.g., collector resistor  $R_C$ , base resistor  $R_B$ , emitter resistor  $R_E$ ).
- Load resistor connected in the collector.

## Capacitors

- Coupling capacitors at input and output to block DC.
- Bypass capacitor across the emitter resistor for AC signals.

## Power Supply

- Typically a 9V or 12V DC supply providing the necessary biasing and operation voltage.

## Input and Output Connections

- Input coupling capacitor connected to the signal source.
- Output taken from the collector or emitter, depending on configuration.

## Working Principle of the Salivahanan CE Amplifier

The CE amplifier operates based on the behavior of the BJT in its active region. The process can be summarized as follows:

- Biasing:

Proper biasing ensures the transistor remains in the active region, where it can amplify signals without distortion. Biasing is achieved through a voltage divider or resistor network setting the base voltage.

- Input Signal Application:

An AC input signal is fed into the base via the coupling capacitor. This signal causes small variations in the base current.



### - Amplification Process:

Due to the transistor's current gain ( $\beta$ ), small changes in base current lead to larger changes in collector current. This results in voltage variations across the collector resistor  $R_C$ .

### - Output Signal:

The amplified output voltage is obtained across the collector resistor, also through a coupling capacitor to prevent DC from reaching subsequent stages or measurement devices.

### - Stability and Biasing Control:

The biasing network stabilizes the operating point, minimizing variations due to temperature changes or transistor parameter variations.

## Design Considerations for the CE Amplifier

Designing an effective CE amplifier involves several important considerations:

### Biasing Method

- Fixed Bias: Simple but less stable against temperature variations.
- Voltage Divider Bias: More stable and preferred for practical applications.
- Emitter Bias: Provides stability with negative feedback.

### Choosing Resistor Values

- Resistors are selected to set the desired quiescent point (Q-point).
- Collector resistor  $R_C$  influences voltage gain.
- Emitter resistor  $R_E$  provides thermal stability.

### Gain Calculation

- Voltage gain ( $A_v$ ) can be approximated by:

$A_v \approx - (R_C / R_E)$ , assuming bypass capacitor is present.

- Input impedance is primarily determined by the base resistor and input capacitance.
- Output impedance is approximately  $RC$ .

## Frequency Response

- Coupling and bypass capacitors influence bandwidth.
- To achieve a wide frequency response, capacitors should be selected with appropriate reactance at the target frequencies.

## Step-by-Step Construction of the Circuit

Constructing the Salivahanan CE amplifier involves systematic steps:

- Connect the power supply (+V) to the collector through the load resistor  $R_C$ .
- Bias the base using a voltage divider network or a resistor from VCC to ground, with a resistor connected to the base.
- Connect the emitter resistor  $R_E$  from the emitter to ground.
- Insert coupling capacitors at the input and output stages.
- Apply the input AC signal through the input coupling capacitor.
- Connect the output across the collector resistor or at the collector terminal.

Proper measurement using a multimeter or oscilloscope can then verify the operation, gain, and frequency response.

## Applications of the Salivahanan CE Amplifier

The CE amplifier's versatility makes it suitable for numerous applications:

- **Audio Amplifiers:** Amplifying audio signals in home theater systems, microphones, and musical instruments.
- **Signal Processing:** Used in radio frequency (RF) circuits for initial amplification stages.
- **Sensor Interfaces:** Amplifying signals from sensors such as thermistors and photodiodes.
- **Educational Demonstrations:** Teaching fundamental concepts of transistor operation and amplification.

## Advantages and Limitations

### Advantages

- Simple design suitable for beginners.
- Provides a good understanding of transistor operation and biasing.
- Offers moderate voltage gain suitable for many applications.
- Cost-effective and easy to assemble.

## Limitations

- Limited bandwidth; not suitable for high-frequency applications without modifications.
- Gain is dependent on transistor parameters, which may vary between units.
- Requires careful biasing for linear operation.
- Temperature stability can be a concern without proper biasing techniques.

## Conclusion

The **electronic circuit 1 salvahanan ce amplifier** serves as an excellent educational tool for understanding the basics of transistor amplification. It encapsulates fundamental concepts such as biasing, load line analysis, and frequency response, providing a practical foundation for students venturing into analog electronics. With proper design and construction, the CE amplifier not only demonstrates core principles but also finds widespread application in various electronic systems.

By mastering this circuit, learners gain valuable skills in circuit analysis, component selection, and troubleshooting?skills that are essential for more advanced electronic design and development. Whether used for academic projects, hobbyist endeavors, or practical applications, the Salvahanan CE amplifier remains a cornerstone in the study of electronic circuits.

### Salivahanan CE Amplifier: An In-Depth Expert Review

#### Introduction to the Salivahanan CE Amplifier

In the world of electronics, amplifiers are fundamental components that serve as the backbone for numerous applications?from audio systems and communication devices to instrumentation and control systems. Among various amplifier configurations, the Common Emitter (CE) amplifier stands out due to its high gain, simplicity, and versatility.

The Salivahanan CE amplifier is a popular educational and practical device, often highlighted in textbooks and laboratories for its straightforward design and robust performance. Developed by the renowned Indian author and educator Salivahanan, this amplifier exemplifies key principles of transistor operation and analog circuit design.

This article delves deeply into the Salivahanan CE amplifier, exploring its structure, working

principles, characteristics, advantages, limitations, and practical applications. Whether you're a student, educator, or practicing engineer, this comprehensive review aims to provide clarity and insight into this essential electronic circuit.

## Overview of the Common Emitter (CE) Amplifier

Before dissecting the Salivahanan-specific model, it is crucial to understand the general concept of the Common Emitter amplifier.

### What Is a CE Amplifier?

A CE amplifier is a bipolar junction transistor (BJT) configuration where:

- The emitter terminal is common to both the input and output circuits.
- The input signal is applied between the base and emitter.
- The output signal is taken between the collector and emitter.

This configuration is renowned for providing voltage amplification, current gain, and power amplification simultaneously, making it suitable for a wide range of electronic applications.

### Structural Components of the Salivahanan CE Amplifier

The Salivahanan CE amplifier, like standard configurations, comprises several key components meticulously arranged to optimize gain and stability.

- Transistor (Q1)
  - Typically an NPN bipolar junction transistor (e.g., BC107, BC109, or similar).
  - Acts as the active device whose current-voltage characteristics enable amplification.
- Biasing Network

Proper biasing ensures the transistor operates in its active region, crucial for linear amplification.

- Biasing Resistors:
  - Base resistor ( $R_B$ ): Provides base current.

- Collector resistor ( $R_C$ ): Determines the collector voltage and current.
- Emitter resistor ( $R_E$ ): Stabilizes bias point and improves linearity.
- Biasing Methods:
  - Voltage divider bias is often used for enhanced stability, with two resistors forming a voltage divider connected to the base.

#### - Coupling and Bypass Capacitors

- Coupling Capacitors ( $C_1$  and  $C_2$ ):
  - Ensure AC signals are transferred between stages without disturbing the DC bias.
  - Typically placed at the input and output.
- Bypass Capacitor ( $C_E$  Bypass):
  - Connected across  $R_E$  to maximize gain by bypassing the emitter resistor at AC frequencies.

#### - Power Supply ( $V_{CC}$ )

- Provides the necessary DC voltage for the circuit.
- Typically in the range of 9V to 30V depending on the transistor specifications.

#### - Input and Output Terminals

- Input ( $V_{in}$ ): Where the AC signal is fed.
- Output ( $V_{out}$ ): Taken across the collector and emitter (or collector and ground depending on configuration).

### Working Principle of the Salivahanan CE Amplifier

The core operation hinges on the transistor's ability to control a large collector current with a smaller base current, thus providing amplification.

### Step-by-Step Operation

- Biasing and Quiescent Point (Q-Point):

- The biasing network establishes a steady-state collector current ( $I_{CQ}$ ) and collector-emitter voltage ( $V_{CEQ}$ ).
- Proper biasing ensures the transistor operates in the forward-active region, avoiding cutoff or saturation.
  
- Input Signal Application:
  - An AC signal (small voltage variation) is superimposed on the base bias.
  - This causes slight variations in the base current ( $I_B$ ).
  
- Transistor Action:
  - The small change in  $I_B$  results in a proportionally larger change in collector current ( $I_C$ ), due to the current gain ( $\beta$ ).
  
- Output Voltage Variation:
  - The variation in  $I_C$  causes a change in voltage across  $R_C$  (collector resistor).
  - This produces an amplified version of the input signal at the collector, which is taken as the output.
  
- Signal Coupling:
  - Capacitors  $C_1$  and  $C_2$  transfer the AC signals while blocking DC components, ensuring the biasing remains unaffected.
  
- Voltage Gain:
  - The overall voltage gain ( $A_V$ ) depends on the load resistor ( $R_C$ ), emitter resistor ( $R_E$ ), bypass capacitor, and transistor parameters.

## Key Characteristics of the Salivahanan CE Amplifier

Understanding the features of the Salivahanan CE amplifier necessitates an exploration of its fundamental parameters.

- Voltage Gain (AV):

- The ratio of the output voltage change to the input voltage change.
- Typically high in CE configurations owing to the transistor's current amplification and load resistor.

- Current Gain (?):

- The ratio of collector current to base current.
- Usually ranges from 100 to 300 for BJTs used in such amplifiers.

- Input and Output Impedance:

- Input Impedance:
  - Moderate, determined by base biasing resistors and the transistor's base-emitter junction.
- Output Impedance:
  - Mainly influenced by RC and the transistor's collector output impedance.

- Frequency Response:

- The amplifier's gain varies with frequency.
- The presence of coupling and bypass capacitors influences the bandwidth.
- Typically designed for mid-band frequencies to maximize gain.

- Power Efficiency:

- The amplifier consumes power from the DC supply, with efficiency depending on biasing and load conditions.

### Advantages of the Salivahanan CE Amplifier

- High Voltage and Power Gain:
- Suitable for amplification of weak signals.
- Ease of Design and Implementation:
- Simple biasing and straightforward circuitry.
- Good Linearity:
- When biased properly, the circuit offers minimal distortion.
- Versatility:
- Applicable in audio amplification, RF circuits, and instrumentation.

### Limitations and Challenges

While the Salivahanan CE amplifier is robust and widely used, it has inherent limitations:

- Bias Stability:
- Sensitive to temperature variations affecting bias point stability.
- Limited Bandwidth:
- Coupling and bypass capacitors introduce frequency-dependent limitations.
- Distortion:
- Non-linearity at large signal amplitudes can cause distortion.
- Power Dissipation:
- Transistor and resistors must handle heat generated during operation.

### Practical Applications of the Salivahanan CE Amplifier

This amplifier configuration is found in numerous practical scenarios:

- Audio Signal Amplifiers:
- Boosting weak audio signals in home and studio systems.
- Radio Frequency Amplifiers:
- Serving as initial stages in RF communication systems.
- Sensor Signal Conditioning:
- Amplifying signals from sensors like thermocouples or photodiodes.
- Instrumentation Amplification:



- Used in measurement and testing equipment requiring precise voltage amplification.

### Design Considerations for the Salivahanan CE Amplifier

Designing an effective CE amplifier involves meticulous selection of components and biasing parameters.

#### - Choosing the Transistor:

- Based on voltage, current, and frequency requirements.
- Ensure the transistor can handle the maximum collector current and voltage.

#### - Biasing Circuit Design:

- Voltage divider bias is preferred for stability.
- Resistors RB1 and RB2 (forming a voltage divider) set the base bias voltage.
- Proper biasing ensures the Q-point is set to prevent clipping and distortion.

#### - Determining Load and Bias Resistors:

- RC is chosen to maximize voltage gain while maintaining safe collector current.
- RE (bypass or unbypassed) influences gain and stability.

#### - Capacitor Selection:

- Coupling and bypass capacitors should be large enough to ensure minimal reactance at the lowest frequency of operation.
- Typically, electrolytic capacitors are used for coupling at audio and RF frequencies.

### Step-by-Step Example of Circuit Analysis

Suppose we design a Salivahanan CE amplifier with the following parameters:

- Transistor: BC109
- VCC: 12V
- RC: 4.7k?
- RE: 1k? (bypassed with a capacitor at AC)
- Biasing resistors: RB1 = 100k?, RB2 = 10k?
- Input signal: 10mV AC

Analysis:

- Calculate the bias point (Q-point) to ensure the transistor operates in the forward-active region.
- Determine the base bias voltage via voltage divider:

\[

$$V_B = V_{CC} \times \frac{R_{B2}}{R_{B1} + R_{B2}} \approx 12V \times \frac{10k?}{110k?} \approx 1.09V$$

\]

- Set the base current (IB) for desired collector current (IC), considering ?.
- Calculate the voltage gain:

\[

$$A_V \approx -\frac{R_C}{R_E}$$

\]

For RE bypassed

QuestionAnswer What is the main purpose of a CE (Common Emitter) amplifier in electronic circuits? The CE amplifier is primarily used to amplify voltage signals, providing high gain and voltage amplification suitable for various electronic applications. How does the Salivahanan CE amplifier differ from other CE amplifier configurations? The Salivahanan CE amplifier typically emphasizes simplified design, stability, and specific biasing techniques to improve performance and ease of understanding for students. What are the key components used in a Salivahanan CE amplifier circuit? Key components include a bipolar junction transistor (BJT), biasing resistors, coupling capacitors, emitter bypass capacitor, and power supply voltage. How do you determine the voltage gain of a Salivahanan CE amplifier? Voltage gain is calculated as the ratio of output voltage to input voltage, often approximated as the collector resistor divided by the emitter resistor

(considering bypassing) in the circuit. What is the role of biasing in the Salivahanan CE amplifier? Biasing establishes the correct operating point (Q-point) of the transistor, ensuring linear amplification and preventing distortion or cutoff during signal variations. How does the frequency response of a Salivahanan CE amplifier look, and what affects it? The frequency response typically exhibits a mid-band flat region, with roll-off at low and high frequencies due to coupling and bypass capacitors, as well as parasitic capacitances. What are common troubleshooting steps if a Salivahanan CE amplifier does not amplify signals correctly? Check transistor biasing, ensure all components are correctly connected, verify capacitor functions, and confirm the power supply voltage is appropriate. How can the input and output impedance of a Salivahanan CE amplifier be optimized? Input impedance is increased by adding base resistors or emitter degeneration, while output impedance can be lowered by proper load matching and circuit design techniques. What are typical applications of the Salivahanan CE amplifier in practical electronics? It is commonly used in audio amplification, signal processing, sensor interfacing, and as a voltage follower in various electronic devices. Why is the Salivahanan CE amplifier considered an essential topic in electronics education? Because it provides foundational understanding of transistor operation, amplification principles, biasing techniques, and circuit analysis, forming the basis for more complex amplifier designs.

**Related keywords:** electronic circuit, CE amplifier, salivahanan, transistor amplifier, common emitter, voltage amplification, biasing circuit, small signal analysis, frequency response, amplifier design

**Read the full article online:** [Electronic Circuit 1 Salivahanan Ce Amplifier](#)